



## 2003-2008 Mazda 6 Rear Floor Bar Install Instructions

## Tool required

- 14mm Wrench (Most vehicles)
- Torque Wrench with 14mm socket
- 3/8 Drive Ratchet

## Contents

- 1 CorkSport Rear Floor bar
- 2 Page Installation Instructions

NOTE: These instructions are provided for reference only. It is recommended that you have a FSM as well. Installation of this bar should take about an hour.

Step 1: Open trunk, and lay rear seats flat. Lift trunk carpet up and back towards the rear of your 6.



Step 2: Remove 14mm head bolt from rear seat brackets, one (1) on each side.

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK



Step 3: Place CorkSport rear bar in vehicle as shown. Using the two (2) original 14mm head bolts removed previously, install bolts through bar and seat brackets and tighten bolts to 34-46ft/lbs.



Step 4: Place trunk carpet back to original position, close seats, doors and trunk. You are finished.

NOTE: The floor carpet covers the bar. If you would like bar to show, trimming of the carpet will be required.



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK.