

CorkSport

MAZDA PERFORMANCE



Installation Instructions for CS Engine Mount Inserts for the Mazda 3/Mazdaspeed 3

Tools needed:

- Jack & jack stands (2)
- 17mm socket
- Optional: Pry bar

Components:

- 1 pair Urethane Engine Mount Inserts
- 2 Page Installation Instructions

Thank you for your purchase. If you have any questions please call CorkSport at 360 260 CORK

Step 1: Jack the front of the car up and use jack stands on the right and left to support it. Underneath the car, loosen and remove the two bolts holding the mount in place. You will need to roll the engine up in order to remove the mount, using a pry bar or another person moving the engine.



Step 2: Install the inserts in the mount and re install the mount. Tighten the bolts to 70 lb/ft.



Step 3: Lower the car and take a drive. The mounts will have a break in time and the feel will change over the first few weeks.

Thank you for your purchase. If you have any questions please call CorkSport at 360 260 CORK